

JUKI HZL DX-5 PISTETE TABEL





1	2	3	4	5	6	7	8	9	0








01	02	03	04	05	06	07	08	09	10
11	12	13	14	15	16	17	18	19	20















01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25
26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50












01	02	03	04	05	06	07	08	09	10	11	12	13	14	15

JUKI HZL DX-5 PISTETE TABEL



@!&'(),.?-./:;
 ABCDEFGHIJKLMNOPQRSTUVWXYZ
 abcdefghijklmnopqrstuvwxyz
 1234567890
 ÄÅÆäääééëëÇçİİñÑÖøöœÜüü

@!&'(),.?-./:;
 ABCDEFGHIJKLMNOPQRS
 TUVWXYZ
 abcdefghijklmnopqrstuvwxyz
 1234567890
 ÄÅÆàäâäëéëÇçİİñÑÖøöœœÜüü

@!&'(),.?-./:;
 ABCDEFGHIJKLMNOPQRSTU
 VWXYZ
 abcdefghijklmnopqrstuvw
 xyz
 1234567890
 ÄÅÆàäâäëéëÇçİİñÑÖøöœœÜüü